



Instructions for using non-woven Photomurals



To prevent the substrate from showing through, it must be homogeneously coloured, clean and smooth.

- 1.** lay out and check the Photomural before applying it, as we cannot be held liable for any gluing costs.
- 2.** to mark the position of the first sheet, use a spirit level and plumb line to draw guide lines on the wall with a pencil.
- 3.** the Photomural can be applied using the wall pasting technique. To do this, apply the paste evenly to the wall in strips using a roller or brush.
- 4.** Press the Photomural onto the wall using a clean cloth, soft roller or brush. Work from top to bottom and from the inside to the outside.

As many walls are not at right angles, we recommend starting with sheet 4.

Drying must be done slowly to avoid gaping at the joint lines and cracking of the Photomural.

Therefore, work at a room temperature of approx. 18-20°C and avoid draughts (keep windows closed, heat moderately in winter).

- 5.** the sheets of non-woven wallpaper are glued butt to butt. Use commercially available paste for non-woven wallpaper.
- 6.** Finally, carefully cut off any excess with a cutter. Immediately dab off any paste residue on the Photomural with a damp sponge or cloth.